

Maxxecu

trigger type	digital
trigger polarity	falling
trig pullup resistor	on
trigger decoder	multitooth + home
home signal	on cam
cam signal position	before TDC
teeth count	24
trigger angle range	260-300 deg

installation instruction:

**Note.** Under no circumstances you move the red wire from it's location  
Nissan uses a white wire for their 12v at the Cas on late modle Skylines and red green for trigger signals  
On Some ecu will require the green and Grey to swap their locations

- 1: Before you remove anything. Make sure you have a timing light and record your engine's base timing so you can set your new sensor trigger offset to match what your base timing was before you remove your stock sensor
- 2: remove stock CAS and set it aside you will need to reuse your 3 M6 bolts
- 3: remove the 4 M7 bolts holding your cam gear on your cam shaft
- 4: install the rotor onto the front of your camgear by lining up the single hole with the dowel hole on your gear using your stock M7 bolts
- 5: install the sensor holder using your stock M6 bolts
- 6: install the sensor by turning the sensor in by hand until it bottom out then back it out 1/4 to 1/2 turn, then lock it in place using a 9/16" wrench.( do not over tighten the nut)
- 7: plug in the connector and zip tie to clear any moving parts
- 8: Start engine and check and adjust trigger offset to get your desire base timing.

Sensor wire funtions as follow

Black= Ground

Red= 12v

Grey= Crank signal which simulate 12 Cam or 24 Crank pulses per engine Revolution

Green= Cam Ref signal which is 1 pulse per engine revolution